



**NOTE:**

- 1.) SERVICE MATERIALS AND DISINFECTION REQUIREMENTS PER KCWA SPECIFICATION UNLESS CITY OR TOWN CODES REQUIRE SPECIFIC MATERIALS THAT HAVE BEEN APPROVED BY KCWA.
- 2.) SERVICE LINE FROM CURB BOX TO BUILDING SHALL BE INSPECTED, TESTED AND APPROVED BY THE LOCAL PLUMBING INSPECTOR.
- 3.) ONCE DISINFECTED FOLD AND CUT SERVICE LINE TO CONNECT TO CURB STOP.
- 4.) BACKFLOW AND VALVES MAY BE PLACED BELOW GRADE IF SECURE PLATE IS USED TO COVER OPEN EXCAVATION.

**TEMPORARY SERVICE CONNECTION**  
**FOR PRESSURE TESTING & DISINFECTION**

NOT TO SCALE